


What's in the box




Setup

1. Download the Alexa app

1. Turn on Bluetooth for your smartphone.
2. Download the latest version of the Alexa app from the app store. The app helps you get more out of your Echo Buds. It's where you set up calling and messaging, and manage music, lists, settings and news.

2. Set up your Echo Buds using the Alexa app

1. Open the Alexa app, then open the Echo Buds case. Wait for the blue LED to pulse, indicating the earbuds are in pairing mode.
2. Place the earbuds in your ears.
3. Tap the notification at the top of the Alexa app, then follow the instructions to set up your Echo Buds. If the notification doesn't appear in the Alexa app, tap the Devices icon on the bottom right of the Alexa app to get started.



Customisable fit

Ear tips

Your Echo Buds come with 3 sizes of ear tips (included). Find the ones that offer a snug and comfortable seal for the best sound.

Wing tips

3 sizes of optional wing tips are provided to help ensure a secure fit.


To install the wing tips:

- Place the left wing tip—marked with an "L"—around the left earbud (also marked with an "L").
- Align the wing tip line with the "L" on the earbud. Verify that the microphones on the front of the earbud aren't covered.*

Positioning your earbuds

- Insert the left earbud into your ear. Gently rotate the earbud to form a good seal. Tuck the optional wing tip under your ear ridge.

*Repeat the above steps for the right earbud.




Default touch gestures

Bose Active Noise Reduction and Pass-through modes

Double-tap the touch sensor on either earbud to switch between Bose Active Noise Reduction mode, which limits background noise, and Pass-through mode to hear your surroundings.

Call controls

When you receive a call, double-tap the touch sensor on either earbud to accept the call. To hang up the call, double-tap again. When you're on a call and a second call is received (call waiting), double-tap to toggle between the calls.



Customising touch gestures

Open the Alexa app, tap the Devices icon on the bottom right, then select Echo & Alexa > Echo Buds > Touch Gestures. You can then reconfigure the touch gestures for each individual earbud to your preference. The options available are:

- Bose Active Noise Reduction and Pass-through modes.
- Activate your smartphone's default voice assistant (Siri or Google Assistant).
- Mute your microphone.
- Pause and play your media.
- Skip to the next track.
- Go back to the previous track.

Auto pause

Removing an Echo Bud from your ear will automatically pause your audio/music. It will resume when you place your earbud back in your ear. This will not impact phone calls.


Using a single earbud

You can choose to use either the left or right Echo Bud independently. If you start with two earbuds and remove one, it will pause the media.

Charging your Echo Buds

To charge your Echo Buds, place them in the charged case. Your new earbuds must be charged prior to using them for an extended period of time.

To recharge the case, plug one end of the included micro-USB cable into the case and the other end (USB-A) into a 5W or higher USB power adaptor that is safety certified for your region.



Always wipe any sweat or moisture from your Echo Buds before charging.

Checking the battery level

Earbuds


To view the battery percentage, check the app or say, "Alexa, what's my battery level?". When your earbuds are in the charging case, press the button on the case to view the battery level. The LED indicator will display the status of the earbud with the lowest battery level.

- Green > 40%
- Yellow < 40%
- Red < 5%

Charging case

The charging case's battery provides your Echo Buds with up to 3 additional full charges. With the earbuds outside of the charging case, press the charging-case button to view the case battery level.

- Green > 1 full charge
- Yellow < 1 full charge
- Red = Battery low



Talking to your Echo Buds

To get started with Alexa on Echo Buds, simply say, "Alexa" and then ask a question. See the included Things to Try card to help you get started.

Pairing your Echo Buds with other devices

To use your Echo Buds with other supported Bluetooth devices, open the charging-case lid, then press the charging-case button for 3 seconds. The light on the front of the case will pulse blue indicating that your Echo Buds are discoverable and ready to pair via Bluetooth. Then place the buds in your ears. On your computer, tablet or other device, go to Bluetooth settings and look for Echo Buds to pair. If you are not pairing your Echo Buds directly with the Alexa app on a smartphone, Alexa functionality will not be available.

For troubleshooting and more information, go to Help & Feedback in the Alexa app.

Give us your feedback

Alexa will improve over time, with new features and ways to get things done. We want to hear about your experiences. Use the Alexa app to send us feedback or visit www.amazon.com/devicesupport.

Troubleshooting setup

If Echo Buds are not showing up under Available Devices, you will need to manually put them into pairing mode. To do this, place both earbuds in the case, leave the charging-case lid open, then press the charging-case button for 3 seconds. The light on the front of the case will pulse blue indicating that your Echo Buds are discoverable and ready to pair via Bluetooth. Verify that your smartphone's Bluetooth is turned on, and then try setting up your Echo Buds again.

If you don't see the blue LED, this may indicate that the battery is low. Place the earbuds in the case, then close the case and wait 15 minutes to charge your earbuds. Try setting up your Echo Buds again.